



型号	蓄能器 升	真空泵 型号	马达电压 伏特	转换开关 型号	D	F	H	重量 Kg	过滤器 附件 型号
DO 20 VTL 5	20	VTL 5	3 ~ 230/400-50Hz	DO 06 92	320	345	270	38.5	FB 20 / FC 20
DO 20 VTL 5 M	20	VTL 5 M	1 ~ 230/50Hz	DO 06 90	320	345	270	39.0	FB 20 / FC 20
DO 20 VTL 6 CC	20	VTL 6 CC	= 24-CC	DO 06 93	400	295	270	34.3	FB 20 / FC 20
DO 20 VTL 10	20	VTL 10	3 ~ 230/400-50Hz	DO 06 92	352	345	270	44.5	FB 20 / FC 20
DO 20 VTL 10 M	20	VTL 10 M	1 ~ 230-50Hz	DO 06 90	352	345	270	45.0	FB 20 / FC 20
DO 20 VTL 10/F	20	VTL 10/F	3 ~ 230/400-50Hz	DO 06 92	390	360	270	49.0	FB 20 / FC 20
DO 20 VTL 10/F M	20	VTL 10/F M	1 ~ 230-50Hz	DO 06 90	390	360	270	49.5	FB 20 / FC 20
DO 20 VTL 15/F	20	VTL 15/F	3 ~ 230/400-50Hz	DO 06 92	410	360	270	51.0	FB 20 / FC 20
DO 20 VTL 15/F M	20	VTL 15/F M	3 ~ 230/400-50Hz	DO 06 90	410	360	270	51.5	FB 20 / FC 20
DO 20 VTL 20/F	20	VTL 20/F	3 ~ 230/400-50Hz	DO 06 92	430	360	270	54.0	FB 20 / FC 20
DO 20 VTL 20/F M	20	VTL 20/F M	1 ~ 230-50Hz	DO 06 90	430	360	270	54.5	FB 20 / FC 20
DO 20 MV 20	20	MV 20	3 ~ 230/400-50Hz	DO 06 92	430	315	270	45.5	FB 20 / FC 20
DO 20 MV 20 M	20	MV 20 M	1 ~ 230-50Hz	DO 06 90	430	315	270	46.0	FB 20 / FC 20

注意：标准的MV20泵在进气口配有FC20系列的过滤器。